



NOTES:

1. A 1/4" X 1/4" SAW-CUT SHALL BE MADE IN THE CONCRETE ALONG ALL LEADING EDGES OF THE COATING.
2. THE SAW-CUT SHALL BE DRIED AND CLEANED OF ALL DUST AND RESIDUE PRIOR TO PRIMING.
3. AREAS NOT TO BE COATED, BUT WHICH ARE ADJACENT TO A LEADING EDGE, SHALL BE NEATLY TAPED OFF AND PROTECTED FROM PRIMER AND TOPCOAT MATERIAL OR OVERSPRAY.
4. PRIMER SHALL BE APPLIED INTO SAW-CUT AREAS.
5. APPLY ELASTO-SHIELD ONTO SAW-CUT AREA, FLOOD INTO SAW-CUT CAVITY WITH TROWEL OR PUTTY KNIFE, AND SMOOTH LEVEL. VERTICAL WILL REQUIRE 2 OR MORE COATS.
6. UPON INITIAL SET OF ELASTO-SHIELD MATERIAL, THE PROTECTIVE TAPE SHALL BE RAZOR-CUT AND REMOVED, LEAVING A STRAIGHT AND NEAT LEADING EDGE.

TNEMEC ELASTO-SHIELD STANDARD LINING DETAILS	
LEADING EDGE TERMINATION DETAIL	
NO. ELS-1	REV. 0